


**piano**

**Instruction manual**

This product is subject to change without prior notice!

## Introduction of function panel



- **Keyboard:** 88 standard keys
- **Tone:** 600 timbres
- **Rhythm:** 600 rhythms
- **Demo:** 88 songs
- **Rhythm function, demonstration music function, recording and playback function**
- **Split:** Double keyboard function, chord function, metronome function
- **Re-Play:** Output function three-digit digital display/LCD display
- **Touch control function**

|     |                       |
|-----|-----------------------|
| 401 | Country 16T 5         |
| 402 | Country Ballad 5      |
| 403 | Country Shuffle 5     |
| 404 | Dream Shuffle 5       |
| 405 | Dream Shuffle Waltz 5 |
| 406 | Fast Beat 5           |
| 407 | Fast Shuffle 5        |
| 408 | Hi Shuffle 5          |
| 409 | Quick Beat 5          |
| 410 | Quick Shuffle 5       |
| 411 | Blue Grass Shuffle 5  |
| 412 | Slow Pure 5           |
| 413 | The Village 5         |
| 414 | Unplugged 16T 5       |
| 415 | Blue Grass 5          |
| 416 | ballad 16T 5          |
| 417 | Bossa Jazz 5          |
| 418 | Bossa Jazz Pad 5      |
| 419 | Even Blue 5           |
| 420 | Even Blue B 5         |
| 421 | Even Jazz 5           |
| 422 | Flow Shuffle 5        |
| 423 | Fusion Shuffle 5      |
| 424 | Happy Blues 5         |
| 425 | Jazz Ballad 5         |
| 426 | Jazz Waltz 5          |
| 427 | Jazz Latin Fusion 5   |
| 428 | Old Blues 5           |
| 429 | Piano Blues 5         |
| 430 | Quick Swing 5         |
| 431 | Slow Blues 5          |
| 432 | Stiff shuffle 5       |
| 433 | Vintage Jazz B 5      |
| 434 | Swing Pad 5           |
| 435 | Swing 5               |
| 436 | Swing2 5              |
| 437 | Swing Pad3 4 5        |
| 438 | Tale Swing 5          |
| 439 | Vintage Jazz 5        |
| 440 | A New Start 5         |
| 441 | Accelerate 5          |
| 442 | Ballad 5              |
| 443 | Coulombs 5            |
| 444 | Drive 5               |
| 445 | Feel 5                |
| 446 | Epiano 5              |
| 447 | Fast Pop 5            |
| 448 | GoodTime 5            |
| 449 | More On 5             |
| 450 | Mystic Ballad 5       |
| 451 | Piano Ballad 5        |
| 452 | Piano Energy 5        |
| 453 | Piano Peace 5         |
| 454 | Pop Hit 5             |
| 455 | Pop Pad 5             |
| 456 | Relaxed 5             |
| 457 | Relaxed Waltz 5       |
| 458 | Sentiment 5           |
| 459 | Simple Ray 5          |
| 460 | Slow Ballad 5         |
| 461 | Smooth Beat 5         |
| 462 | Snake Base 5          |
| 463 | Toms 5                |
| 464 | Toms B 5              |
| 465 | True Ballad 5         |
| 466 | True Ballad Waltz 5   |
| 467 | Two Guitars 5         |
| 468 | Toms C 5              |
| 469 | Unwind 5              |
| 470 | Airy Rock 5           |
| 471 | Bass Up 5             |
| 472 | Dirty Shuffle 5       |
| 473 | Flat Rock 5           |
| 474 | Flow Rock 5           |
| 475 | Ground State 5        |
| 476 | Heart Rock 5          |
| 477 | Light Rock 5          |
| 478 | Old Rock Ballad 5     |
| 479 | Quarter Rock 5        |
| 480 | Rock Base 5           |
| 481 | Rock Base B 5         |
| 482 | Rock Base C 5         |
| 483 | Rock Base D 5         |
| 484 | Rock Base E 5         |
| 485 | Rock Base F 5         |
| 486 | Rock Roll 5           |
| 487 | Rock Run 5            |
| 488 | Rock Tain 5           |
| 489 | Shuffle 5             |
| 490 | Shuffle Waltz 5       |
| 491 | Slow Rock 5           |
| 492 | Slow Rock9 8 5        |
| 493 | Square Beat 5         |
| 494 | Steady Beat 5         |
| 495 | Sustain 5             |
| 496 | Toms Rock 5           |
| 497 | Twist 5               |
| 498 | Bossa Nova 5          |
| 499 | Chacha 5              |
| 500 | bossa Waltz 5         |

|     |                       |
|-----|-----------------------|
| 501 | Country 16T 6         |
| 502 | Country Ballad 6      |
| 503 | Country Shuffle 6     |
| 504 | Dream Shuffle 6       |
| 505 | Dream Shuffle Waltz 6 |
| 506 | Fast Beat 6           |
| 507 | Fast Shuffle 6        |
| 508 | Hi Shuffle 6          |
| 509 | Quick Beat 6          |
| 510 | Quick Shuffle 6       |
| 511 | Blue Grass Shuffle 6  |
| 512 | Slow Pure 6           |
| 513 | The Village 6         |
| 514 | Unplugged 16T 6       |
| 515 | Blue Grass 6          |
| 516 | ballad 16T 6          |
| 517 | Bossa Jazz 6          |
| 518 | Bossa Jazz Pad 6      |
| 519 | Even Blue 6           |
| 520 | Even Blue B 6         |
| 521 | Even Jazz 6           |
| 522 | Flow Shuffle 6        |
| 523 | Fusion Shuffle 6      |
| 524 | Happy Blues 6         |
| 525 | Jazz Ballad 6         |
| 526 | Jazz Waltz 6          |
| 527 | Jazz Latin Fusion 6   |
| 528 | Old Blues 6           |
| 529 | Piano Blues 6         |
| 530 | Quick Swing 6         |
| 531 | Slow Blues 6          |
| 532 | Stiff shuffle 6       |
| 533 | Vintage Jazz B 6      |
| 534 | Swing Pad 6           |
| 535 | Swing 6               |
| 536 | Swing2 6              |
| 537 | Swing Pad3 4 6        |
| 538 | Tale Swing 6          |
| 539 | Vintage Jazz 6        |
| 540 | A New Start 6         |
| 541 | Accelerate 6          |
| 542 | Ballad 6              |
| 543 | Coulombs 6            |
| 544 | Drive 6               |
| 545 | Feel 6                |
| 546 | Epiano 6              |
| 547 | Fast Pop 6            |
| 548 | GoodTime 6            |
| 549 | More On 6             |
| 550 | Mystic Ballad 6       |
| 551 | Piano Ballad 6        |
| 552 | Piano Energy 6        |
| 553 | Piano Peace 6         |
| 554 | Pop Hit 6             |
| 555 | Pop Pad 6             |
| 556 | Relaxed 6             |
| 557 | Relaxed Waltz 6       |
| 558 | Sentiment 6           |
| 559 | Simple Ray 6          |
| 560 | Slow Ballad 6         |
| 561 | Smooth Beat 6         |
| 562 | Snake Base 6          |
| 563 | Toms 6                |
| 564 | Toms B 6              |
| 565 | True Ballad 6         |
| 566 | True Ballad Waltz 6   |
| 567 | Two Guitars 6         |
| 568 | Toms C 6              |
| 569 | Unwind 6              |
| 570 | Airy Rock 6           |
| 571 | Bass Up 6             |
| 572 | Dirty Shuffle 6       |
| 573 | Flat Rock 6           |
| 574 | Flow Rock 6           |
| 575 | Ground State 6        |
| 576 | Heart Rock 6          |
| 577 | Light Rock 6          |
| 578 | Old Rock Ballad 6     |
| 579 | Quarter Rock 6        |
| 580 | Rock Base 6           |
| 581 | Rock Base B 6         |
| 582 | Rock Base C 6         |
| 583 | Rock Base D 6         |
| 584 | Rock Base E 6         |
| 585 | Rock Base F 6         |
| 586 | Rock Roll 6           |
| 587 | Rock Run 6            |
| 588 | Rock Tain 6           |
| 589 | Shuffle 6             |
| 590 | Shuffle Waltz 6       |
| 591 | Slow Rock 6           |
| 592 | Slow Rock9 8 6        |
| 593 | Square Beat 6         |
| 594 | Steady Beat 6         |
| 595 | Sustain 6             |
| 596 | Toms Rock 6           |
| 597 | Twist 6               |
| 598 | Bossa Nova 6          |
| 599 | Chacha 6              |
|     |                       |

# Rhythm List

# Manual for electric piano

|     |                       |
|-----|-----------------------|
| 001 | Country 16T           |
| 002 | Country Ballad 3      |
| 003 | Country Shuffle       |
| 004 | Dream Shuffle         |
| 005 | Dream Shuffle Waltz 3 |
| 006 | Fast Beat             |
| 007 | Fast Shuffle          |
| 008 | HI Shuffle            |
| 009 | Quick Beat            |
| 010 | Quick Shuffle         |
| 011 | Blue Grass Shuffle    |
| 012 | Slow Pure             |
| 013 | The Village           |
| 014 | Unplugged 16T         |
| 015 | Blue Grass            |
| 016 | ballad 16T 3          |
| 017 | Bossa Jazz            |
| 018 | Bossa Jazz Pad        |
| 019 | Even Blue             |
| 020 | Even Blue B           |
| 021 | Even Jazz             |
| 022 | Flow Shuffle          |
| 023 | Fusion Shuffle        |
| 024 | Happy Blues           |
| 025 | Jazz Ballad           |
| 026 | Jazz Waltz            |
| 027 | Jazz Latin Fusion     |
| 028 | Old Blues             |
| 029 | Piano Blues           |
| 030 | Quick Swing           |
| 031 | Slow Blues            |
| 032 | Stiff shuffle         |
| 033 | Vintage Jazz B        |
| 034 | Swing Pad             |
| 035 | Swing                 |
| 036 | Swing2                |
| 037 | Swing Pad3 4          |
| 038 | Tale Swing            |
| 039 | Vintage Jazz          |
| 040 | A New Start           |
| 041 | Accelerate            |
| 042 | Ballad                |
| 043 | Coulombs              |
| 044 | Drive                 |
| 045 | Feel                  |
| 046 | Epiano                |
| 047 | Fast Pop              |
| 048 | GoodTime              |
| 049 | Move On               |
| 050 | Mystic Ballad         |
| 051 | Piano Ballad          |
| 052 | Piano Energy          |
| 053 | Piano Peace           |
| 054 | Pop Hit               |
| 055 | Pop Pad               |
| 056 | Relaxed               |
| 057 | Relaxed Waltz         |
| 058 | Sentiment             |
| 059 | Simple Way            |
| 060 | Slow Ballad           |
| 061 | Smooth Beat           |
| 062 | Snake Base            |
| 063 | Toms                  |
| 064 | Toms B                |
| 065 | True Ballad           |
| 066 | True Ballad Waltz     |
| 067 | Two Guitars           |
| 068 | Toms C                |
| 069 | Unwind                |
| 070 | Airy Rock             |
| 071 | Bass Up               |
| 072 | Dirty Shuffle         |
| 073 | Flat Rock             |
| 074 | Flow Rock             |
| 075 | Ground State          |
| 076 | Heart Rock            |
| 077 | Light Rock            |
| 078 | Old Rock Ballad       |
| 079 | Quarter Rock          |
| 080 | Rock Base             |
| 081 | Rock Base B           |
| 082 | Rock Base C           |
| 083 | Rock Base D           |
| 084 | Rock Base E           |
| 085 | Rock Base F           |
| 086 | Rock Roll             |
| 087 | Rock Run              |
| 088 | Rock Tain             |
| 089 | Shuffle               |
| 090 | Shuffle Waltz         |
| 091 | Slow Rock             |
| 092 | Slow Rock9 8          |
| 093 | Square Beat           |
| 094 | Steady Beat           |
| 095 | Sustain               |
| 096 | Toms Rock             |
| 097 | Twist                 |
| 098 | Bossa Nova            |
| 099 | Chacha                |
| 100 | bossa Waltz           |

|     |                       |
|-----|-----------------------|
| 201 | Country 16T 3         |
| 202 | Country Ballad 3      |
| 203 | Country Shuffle 3     |
| 204 | Dream Shuffle 3       |
| 205 | Dream Shuffle Waltz 3 |
| 206 | Fast Beat 3           |
| 207 | Fast Shuffle 3        |
| 208 | HI Shuffle 3          |
| 209 | Quick Beat 3          |
| 210 | Quick Shuffle 3       |
| 211 | Blue Grass Shuffle 3  |
| 212 | Slow Pure 3           |
| 213 | The Village 3         |
| 214 | Unplugged 16T 3       |
| 215 | Blue Grass 3          |
| 216 | ballad 16T 3          |
| 217 | Bossa Jazz 3          |
| 218 | Bossa Jazz Pad 3      |
| 219 | Even Blue 3           |
| 220 | Even Blue B 3         |
| 221 | Even Jazz 3           |
| 222 | Flow Shuffle 3        |
| 223 | Fusion Shuffle 3      |
| 224 | Happy Blues 3         |
| 225 | Jazz Ballad 3         |
| 226 | Jazz Waltz 3          |
| 227 | Jazz Latin Fusion 3   |
| 228 | Old Blues 3           |
| 229 | Piano Blues 3         |
| 230 | Quick Swing 3         |
| 231 | Slow Blues 3          |
| 232 | Stiff shuffle 3       |
| 233 | Vintage Jazz B 3      |
| 234 | Swing Pad 3           |
| 235 | Swing 3               |
| 236 | Swing2 3              |
| 237 | Swing Pad3 4 3        |
| 238 | Tale Swing 3          |
| 239 | Vintage Jazz 3        |
| 240 | A New Start 3         |
| 241 | Accelerate 3          |
| 242 | Ballad 3              |
| 243 | Coulombs 3            |
| 244 | Drive 3               |
| 245 | Feel 3                |
| 246 | Epiano 3              |
| 247 | Fast Pop 3            |
| 248 | GoodTime 3            |
| 249 | Move On 3             |
| 250 | Mystic Ballad 3       |
| 251 | Piano Ballad 3        |
| 252 | Piano Energy 3        |
| 253 | Piano Peace 3         |
| 254 | Pop Hit 3             |
| 255 | Pop Pad 3             |
| 256 | Relaxed 3             |
| 257 | Relaxed Waltz 3       |
| 258 | Sentiment 3           |
| 259 | Simple Way 3          |
| 260 | Slow Ballad 3         |
| 261 | Smooth Beat 3         |
| 262 | Snake Base 3          |
| 263 | Toms 3                |
| 264 | Toms B 3              |
| 265 | True Ballad 3         |
| 266 | True Ballad Waltz 3   |
| 267 | Two Guitars 3         |
| 268 | Toms C 3              |
| 269 | Unwind 3              |
| 270 | Airy Rock 3           |
| 271 | Bass Up 3             |
| 272 | Dirty Shuffle 3       |
| 273 | Flat Rock 3           |
| 274 | Flow Rock 3           |
| 275 | Ground State 3        |
| 276 | Heart Rock 3          |
| 277 | Light Rock 3          |
| 278 | Old Rock Ballad 3     |
| 279 | Quarter Rock 3        |
| 280 | Rock Base 3           |
| 281 | Rock Base B 3         |
| 282 | Rock Base C 3         |
| 283 | Rock Base D 3         |
| 284 | Rock Base E 3         |
| 285 | Rock Base F 3         |
| 286 | Rock Roll 3           |
| 287 | Rock Run 3            |
| 288 | Rock Tain 3           |
| 289 | Shuffle 3             |
| 290 | Shuffle Waltz 3       |
| 291 | Slow Rock 3           |
| 292 | Slow Rock9 8 3        |
| 293 | Square Beat 3         |
| 294 | Steady Beat 3         |
| 295 | Sustain 3             |
| 296 | Toms Rock 3           |
| 297 | Twist 3               |
| 298 | Bossa Nova 3          |
| 299 | Chacha 3              |
| 300 | bossa Waltz 3         |

|     |                       |
|-----|-----------------------|
| 201 | Country 16T 3         |
| 202 | Country Ballad 3      |
| 203 | Country Shuffle 3     |
| 204 | Dream Shuffle 3       |
| 205 | Dream Shuffle Waltz 3 |
| 206 | Fast Beat 3           |
| 207 | Fast Shuffle 3        |
| 208 | HI Shuffle 3          |
| 209 | Quick Beat 3          |
| 210 | Quick Shuffle 3       |
| 211 | Blue Grass Shuffle 3  |
| 212 | Slow Pure 3           |
| 213 | The Village 3         |
| 214 | Unplugged 16T 3       |
| 215 | Blue Grass 3          |
| 216 | ballad 16T 3          |
| 217 | Bossa Jazz 3          |
| 218 | Bossa Jazz Pad 3      |
| 219 | Even Blue 3           |
| 220 | Even Blue B 3         |
| 221 | Even Jazz 3           |
| 222 | Flow Shuffle 3        |
| 223 | Fusion Shuffle 3      |
| 224 | Happy Blues 3         |
| 225 | Jazz Ballad 3         |
| 226 | Jazz Waltz 3          |
| 227 | Jazz Latin Fusion 3   |
| 228 | Old Blues 3           |
| 229 | Piano Blues 3         |
| 230 | Quick Swing 3         |
| 231 | Slow Blues 3          |
| 232 | Stiff shuffle 3       |
| 233 | Vintage Jazz B 3      |
| 234 | Swing Pad 3           |
| 235 | Swing 3               |
| 236 | Swing2 3              |
| 237 | Swing Pad3 4 3        |
| 238 | Tale Swing 3          |
| 239 | Vintage Jazz 3        |
| 240 | A New Start 3         |
| 241 | Accelerate 3          |
| 242 | Ballad 3              |
| 243 | Coulombs 3            |
| 244 | Drive 3               |
| 245 | Feel 3                |
| 246 | Epiano 3              |
| 247 | Fast Pop 3            |
| 248 | GoodTime 3            |
| 249 | Move On 3             |
| 250 | Mystic Ballad 3       |
| 251 | Piano Ballad 3        |
| 252 | Piano Energy 3        |
| 253 | Piano Peace 3         |
| 254 | Pop Hit 3             |
| 255 | Pop Pad 3             |
| 256 | Relaxed 3             |
| 257 | Relaxed Waltz 3       |
| 258 | Sentiment 3           |
| 259 | Simple Way 3          |
| 260 | Slow Ballad 3         |
| 261 | Smooth Beat 3         |
| 262 | Snake Base 3          |
| 263 | Toms 3                |
| 264 | Toms B 3              |
| 265 | True Ballad 3         |
| 266 | True Ballad Waltz 3   |
| 267 | Two Guitars 3         |
| 268 | Toms C 3              |
| 269 | Unwind 3              |
| 270 | Airy Rock 3           |
| 271 | Bass Up 3             |
| 272 | Dirty Shuffle 3       |
| 273 | Flat Rock 3           |
| 274 | Flow Rock 3           |
| 275 | Ground State 3        |
| 276 | Heart Rock 3          |
| 277 | Light Rock 3          |
| 278 | Old Rock Ballad 3     |
| 279 | Quarter Rock 3        |
| 280 | Rock Base 3           |
| 281 | Rock Base B 3         |
| 282 | Rock Base C 3         |
| 283 | Rock Base D 3         |
| 284 | Rock Base E 3         |
| 285 | Rock Base F 3         |
| 286 | Rock Roll 3           |
| 287 | Rock Run 3            |
| 288 | Rock Tain 3           |
| 289 | Shuffle 3             |
| 290 | Shuffle Waltz 3       |
| 291 | Slow Rock 3           |
| 292 | Slow Rock9 8 3        |
| 293 | Square Beat 3         |
| 294 | Steady Beat 3         |
| 295 | Sustain 3             |
| 296 | Toms Rock 3           |
| 297 | Twist 3               |
| 298 | Bossa Nova 3          |
| 299 | Chacha 3              |
| 300 | bossa Waltz 3         |

|     |                       |
|-----|-----------------------|
| 301 | Country 16T 4         |
| 302 | Country Ballad 4      |
| 303 | Country Shuffle 4     |
| 304 | Dream Shuffle 4       |
| 305 | Dream Shuffle Waltz 4 |
| 306 | Fast Beat 4           |
| 307 | Fast Shuffle 4        |
| 308 | HI Shuffle 4          |
| 309 | Quick Beat 4          |
| 310 | Quick Shuffle 4       |
| 311 | Blue Grass Shuffle 4  |
| 312 | Slow Pure 4           |
| 313 | The Village 4         |
| 314 | Unplugged 16T 4       |
| 315 | Blue Grass 4          |
| 316 | ballad 16T 4          |
| 317 | Bossa Jazz 4          |
| 318 | Bossa Jazz Pad 4      |
| 319 | Even Blue 4           |
| 320 | Even Blue B 4         |
| 321 | Even Jazz 4           |
| 322 | Flow Shuffle 4        |
| 323 | Fusion Shuffle 4      |
| 324 | Happy Blues 4         |
| 325 | Jazz Ballad 4         |
| 326 | Jazz Waltz 4          |
| 327 | Jazz Latin Fusion 4   |
| 328 | Old Blues 4           |
| 329 | Piano Blues 4         |
| 330 | Quick Swing 4         |
| 331 | Slow Blues 4          |
| 332 | Stiff shuffle 4       |
| 333 | Vintage Jazz B 4      |
| 334 | Swing Pad 4           |
| 335 | Swing 4               |
| 336 | Swing2 4              |
| 337 | Swing Pad3 4 4        |
| 338 | Tale Swing 4          |
| 339 | Vintage Jazz 4        |
| 340 | A New Start 4         |
| 341 | Accelerate 4          |
| 342 | Ballad 4              |
| 343 | Coulombs 4            |
| 344 | Drive 4               |
| 345 | Feel 4                |
| 346 | Epiano 4              |
| 347 | Fast Pop 4            |
| 348 | GoodTime 4            |
| 349 | Move On 4             |
| 350 | Mystic Ballad 4       |
| 351 | Piano Ballad 4        |
| 352 | Piano Energy 4        |
| 353 | Piano Peace 4         |
| 354 | Pop Hit 4             |
| 355 | Pop Pad 4             |
| 356 | Relaxed 4             |
| 357 | Relaxed Waltz 4       |
| 358 | Sentiment 4           |
| 359 | Simple Way 4          |
| 360 | Slow Ballad 4         |
| 361 | Smooth Beat 4         |
| 362 | Snake Base 4          |
| 363 | Toms 4                |
| 364 | Toms B 4              |
| 365 | True Ballad 4         |
| 366 | True Ballad Waltz 4   |
| 367 | Two Guitars 4         |
| 368 | Toms C 4              |
| 369 | Unwind 4              |
| 370 | Airy Rock 4           |
| 371 | Bass Up 4             |
| 372 | Dirty Shuffle 4       |
| 373 | Flat Rock 4           |
| 374 | Flow Rock 4           |
| 375 | Ground State 4        |
| 376 | Heart Rock 4          |
| 377 | Light Rock 4          |
| 378 | Old Rock Ballad 4     |
| 379 | Quarter Rock 4        |
| 380 | Rock Base 4           |
| 381 | Rock Base B 4         |
| 382 | Rock Base C 4         |
| 383 | Rock Base D 4         |
| 384 | Rock Base E 4         |
| 385 | Rock Base F 4         |
| 386 | Rock Roll 4           |
| 387 | Rock Run 4            |
| 388 | Rock Tain 4           |
| 389 | Shuffle 4             |
| 390 | Shuffle Waltz 4       |
| 391 | Slow Rock 4           |
| 392 | Slow Rock9 8 4        |
| 393 | Square Beat 4         |
| 394 | Steady Beat 4         |
| 395 | Sustain 4             |
| 396 | Toms Rock 4           |
| 397 | Twist 4               |
| 398 | Bossa Nova 4          |
| 399 | Chacha 4              |
| 400 | bossa Waltz 4         |

## Note:

1. The product is configured with a 5V power adapter.
2. Do not use more than 5V power adapter,otherwise it will easily cause the product to burn or even cause fire.
3. If it is not used for a long time, unplug the power adapter.

## Metronome features:

1. Metronome is a metronome auxiliary function. Press the Metronome key to select the metronome.
2. There are four variations of the metronome, which are 1/4 beat --2/4 beat – 3/4 beat --4/4 beat.

## Volume key function:

Rotation (data wheel) can adjust the volume.

## Playing tone pattern:

1. Press the power switch to automatically enter the playing mode.
2. Press the tone key, then press Select -, select + to select different timbre

## Rhythm pattern:

1. Press [Start/Stop] [Rhythm]. The system enters the rhythm mode and plays the rhythm.
2. Press the rhythm key, then press Select -, select + to select different rhythm tracks, tracks from 0-599.
3. Press the "Sync" key. When you press the piano key, the rhythm will play simultaneously.

## Model:

1. Press the demonstration song button to play the demonstration song.
2. Press Select -, Select + to select different demonstration tracks from 0-87.

## Recording related functions:

1. Press [Record] to start recording the sound of the performance
2. Press [Play] to play the recorded sound.

## Chord pattern:

1. When the system is playing the rhythm, press the "chord" key on the left hand keyboard to switch to the automatic chord mode.
2. Chord function: Press the keys in chord mode to play chords that match the rhythm and the tone of the chords  
It changes with the pitch of the keys.

## Setting mode:

1. Press [Settings] key continuously: press Select -, select +, select the required adjustment.
2. The digital display 1 is the [strength] key, then press Select -, select + to turn on or off the strength function
3. The digital display 2 is the [speed] key, then press Select -, select + key to adjust the speed 20-280.
4. The digital display 3 is the "shift" key, then press select -, select + key to adjust the tone -12--+12.
5. Digit display 4 is [dual keyboard], then press select -, select + key to enable or disable the dual keyboard mode.
6. The digital display 5 is [double tone], then press select -, select + to enable or disable the double tone function.
7. Digit display 6 is used to restore factory Settings.

## Usb flash drive playback:

1. After the USB flash drive is inserted, the songs on the USB flash drive are automatically played.
2. Press Play/Pause to play the paused song.
3. Press the previous song and select the song you want to play next.

|     |                           |
|-----|---------------------------|
| 401 | Drawbar Organ 3           |
| 402 | Percussive Organ 3        |
| 403 | Rock Organ 3              |
| 404 | Church Organ 3            |
| 405 | Reed Organ 3              |
| 406 | Accordion 3               |
| 407 | Harmonica 3               |
| 408 | Tango Accordion 3         |
| 409 | Acoustic Guitar (nylon) 3 |
| 410 | Acoustic Guitar (steel) 3 |
| 411 | Electric Guitar (jazz) 3  |
| 412 | Electric Guitar (clean) 3 |
| 413 | Electric Guitar (muted) 3 |
| 414 | Overtone Guitar 3         |
| 415 | Distortion Guitar 3       |
| 416 | Guitar Harmonics 3        |
| 417 | Acoustic Bass 3           |
| 418 | Electric Bass (finger) 3  |
| 419 | Electric Bass (pick) 3    |
| 420 | Fretless Bass 3           |
| 421 | Slap Bass 1 3             |
| 422 | Slap Bass 2 3             |
| 423 | Synth Bass 1 3            |
| 424 | Synth Bass 2 3            |
| 425 | Violin 3                  |
| 426 | Viola 3                   |
| 427 | Cello 3                   |
| 428 | Contrabass 3              |
| 429 | Tremolo Strings 3         |
| 430 | Pizzicato Strings 3       |
| 431 | Orchestral Harp 3         |
| 432 | Timpani 3                 |
| 433 | String Ensemble 1 3       |
| 434 | String Ensemble 2 3       |
| 435 | Synth Strings 1 3         |
| 436 | Synth Strings 2 3         |
| 437 | Choir Aahs 3              |
| 438 | Voice Oohs 3              |
| 439 | Synth Voice 3             |
| 440 | Orchestra Hit 3           |
| 441 | Trumpet 3                 |
| 442 | Trombone 3                |
| 443 | Tuba 3                    |
| 444 | Muted Trumpet 3           |
| 445 | French Horn 3             |
| 446 | Brass Section 3           |
| 447 | Synth Brass 1 3           |
| 448 | Synth Brass 2 3           |
| 449 | Soprano Sax 3             |
| 450 | Alto Sax 3                |
| 451 | Tenor Sax 3               |
| 452 | Baritone Sax 3            |
| 453 | Oboe 3                    |
| 454 | English Horn 3            |
| 455 | Bassoon 3                 |
| 456 | Clarinet 3                |
| 457 | Piccolo 3                 |
| 458 | Flute 3                   |
| 459 | Recorder 3                |
| 460 | Pan Flute 3               |
| 461 | Bloom Bottle 3            |
| 462 | Shakuhachi 3              |
| 463 | Whistle 3                 |
| 464 | Ocarina 3                 |
| 465 | Lead 1 (square) 3         |
| 466 | Lead 2 (sawtooth) 3       |
| 467 | Lead 3 (calliope) 3       |
| 468 | Lead 4 (chiff) 3          |
| 469 | Lead 5 (charang) 3        |
| 470 | Lead 6 (voice) 3          |
| 471 | Lead 7 (fifths) 3         |
| 472 | Lead 8 (bass + lead) 3    |
| 473 | Pad 1 (new age) 3         |
| 474 | Pad 2 (warm) 3            |
| 475 | Pad 3 (polysynth) 3       |
| 476 | Pad 4 (choir) 3           |
| 477 | Pad 5 (bowed) 3           |
| 478 | Pad 6 (metallic) 3        |
| 479 | Pad 7 (halo) 3            |
| 480 | Pad 8 (sweep) 3           |
| 481 | FX 1 (rain) 3             |
| 482 | FX 2 (soundtrack) 3       |
| 483 | FX 3 (crystal) 3          |
| 484 | FX 4 (atmosphere) 3       |
| 485 | FX 5 (brightness) 3       |
| 486 | FX 6 (goblins) 3          |
| 487 | FX 7 (echoes) 3           |
| 488 | FX 8 (sci-fi) 3           |
| 489 | Sitar 3                   |
| 490 | Banjo 3                   |
| 491 | Shamisen 3                |
| 492 | Koto 3                    |
| 493 | Kalimba 3                 |
| 494 | Bugpipe 3                 |
| 495 | Fiddle 3                  |
| 496 | Sham 3                    |
| 497 | Twinkle Bell 3            |
| 498 | Agogo 3                   |
| 499 | Steel Drums 3             |
| 500 | Woodblock 3               |

|     |                           |
|-----|---------------------------|
| 501 | Taiko Drum 3              |
| 502 | Melodic Tom 3             |
| 503 | Synth Drum 3              |
| 504 | Reverse Cymbal 3          |
| 505 | Guitar Fret Noise 3       |
| 506 | Breath Noise 3            |
| 507 | Seashore 3                |
| 508 | Bird Tweet 3              |
| 509 | Telephone Ring 3          |
| 510 | Helicopter 3              |
| 511 | Applause 3                |
| 512 | Gunshot 4                 |
| 513 | Acoustic Grand Piano 4    |
| 514 | Bright Acoustic Piano 4   |
| 515 | Electric Grand Piano 4    |
| 516 | Honky-tonk Piano 4        |
| 517 | Electric Piano 1 4        |
| 518 | Electric Piano 2 4        |
| 519 | Harpsichord 4             |
| 520 | Clavinet 4                |
| 521 | Celesta 4                 |
| 522 | Glockenspiel 4            |
| 523 | Musie Box 4               |
| 524 | Vibraphone 4              |
| 525 | Marimba 4                 |
| 526 | Xylophone 4               |
| 527 | Tubular Bells 4           |
| 528 | Dulcimer 4                |
| 529 | Drawbar Organ 4           |
| 530 | Percussive Organ 4        |
| 531 | Rock Organ 4              |
| 532 | Church Organ 4            |
| 533 | Reed Organ 4              |
| 534 | Accordion 4               |
| 535 | Harmonica 4               |
| 536 | Tango Accordion 4         |
| 537 | Acoustic Guitar (nylon) 4 |
| 538 | Acoustic Guitar (steel) 4 |
| 539 | Electric Guitar (jazz) 4  |
| 540 | Electric Guitar (clean) 4 |
| 541 | Electric Guitar (muted) 4 |
| 542 | Overtone Guitar 4         |
| 543 | Distortion Guitar 4       |
| 544 | Guitar Harmonics 4        |
| 545 | Acoustic Bass 4           |
| 546 | Electric Bass (finger) 4  |
| 547 | Electric Bass (pick) 4    |
| 548 | Fretless Bass 4           |
| 549 | Slap Bass 1 4             |
| 550 | Slap Bass 2 4             |
| 551 | Synth Bass 1 4            |
| 552 | Synth Bass 2 4            |
| 553 | Violin 4                  |
| 554 | Viola 4                   |
| 555 | Cello 4                   |
| 556 | Contrabass 4              |
| 557 | Tremolo Strings 4         |
| 558 | Pizzicato Strings 4       |
| 559 | Orchestral Harp 4         |
| 560 | Timpani 4                 |
| 561 | String Ensemble 1 4       |
| 562 | String Ensemble 2 4       |
| 563 | Synth Strings 1 4         |
| 564 | Synth Strings 2 4         |
| 565 | Choir Aahs 4              |
| 566 | Voice Oohs 4              |
| 567 | Synth Voice 4             |
| 568 | Orchestra Hit 4           |
| 569 | Trumpet 4                 |
| 570 | Trombone 4                |
| 571 | Tuba 4                    |
| 572 | Muted Trumpet 4           |
| 573 | French Horn 4             |
| 574 | Brass Section 4           |
| 575 | Synth Brass 1 4           |
| 576 | Synth Brass 2 4           |
| 577 | Soprano Sax 4             |
| 578 | Alto Sax 4                |
| 579 | Tenor Sax 4               |
| 580 | Baritone Sax 4            |
| 581 | Oboe 4                    |
| 582 | English Horn 4            |
| 583 | Bassoon 4                 |
| 584 | Clarinet 4                |
| 585 | Piccolo 4                 |
| 586 | Flute 4                   |
| 587 | Recorder 4                |
| 588 | Pan Flute 4               |
| 589 | Bloom Bottle 4            |
| 590 | Shakuhachi 4              |
| 591 | Whistle 4                 |
| 592 | Ocarina 4                 |
| 593 | Lead 1 (square) 4         |
| 594 | Lead 2 (sawtooth) 4       |
| 595 | Lead 3 (calliope) 4       |
| 596 | Lead 4 (chiff) 4          |
| 597 | Lead 5 (charang) 4        |
| 598 | Lead 6 (voice) 4          |
| 599 | Lead 7 (fifths) 4         |

# Tone list

# Manual for electric piano


|     |                         |
|-----|-------------------------|
| 001 | Acoustic Grand Piano    |
| 002 | Bright Acoustic Piano   |
| 003 | Electric Grand Piano    |
| 004 | Honky-tonk Piano        |
| 005 | Electric Piano 1        |
| 006 | Electric Piano 2        |
| 007 | Harpsichord             |
| 008 | Clavinet                |
| 009 | Celesta                 |
| 010 | Glockenspiel            |
| 011 | Music Box               |
| 012 | Vibraphone              |
| 013 | Marimba                 |
| 014 | Xylophone               |
| 015 | Tubular Bells           |
| 016 | Dulcimer                |
| 017 | Drawbar Organ           |
| 018 | Percussive Organ        |
| 019 | Rock Organ              |
| 020 | Church Organ            |
| 021 | Reed Organ              |
| 022 | Accordion               |
| 023 | Harmonica               |
| 024 | Tango Accordion         |
| 025 | Acoustic Guitar (nylon) |
| 026 | Acoustic Guitar (steel) |
| 027 | Electric Guitar (Jazz)  |
| 028 | Electric Guitar (clean) |
| 029 | Electric Guitar (muted) |
| 030 | Overdriven Guitar       |
| 031 | Distortion Guitar       |
| 032 | Guitar Harmonics        |
| 033 | Acoustic Bass           |
| 034 | Electric Bass (finger)  |
| 035 | Electric Bass (pick)    |
| 036 | Fretless Bass           |
| 037 | Slap Bass 1             |
| 038 | Slap Bass 2             |
| 039 | Synth Bass 1            |
| 040 | Synth Bass 2            |
| 041 | Violin                  |
| 042 | Viola                   |
| 043 | Cello                   |
| 044 | Contrabass              |
| 045 | Tremolo Strings         |
| 046 | Pizzicato Strings       |
| 047 | Orchestral Harp         |
| 048 | Timpani                 |
| 049 | String Ensemble 1       |
| 050 | String Ensemble 2       |
| 051 | Synth Strings 1         |
| 052 | Synth Strings 2         |
| 053 | Choir Aahs              |
| 054 | Voice Oohs              |
| 055 | Synth Voice             |
| 056 | Orchestra Hit           |
| 057 | Trumpet                 |
| 058 | Trombone                |
| 059 | Tuba                    |
| 060 | Muted Trumpet           |
| 061 | French Horn             |
| 062 | Brass Section           |
| 063 | Synth Brass 1           |
| 064 | Synth Brass 2           |
| 065 | Soprano Sax             |
| 066 | Alto Sax                |
| 067 | Tenor Sax               |
| 068 | Baritone Sax            |
| 069 | Oboe                    |
| 070 | English Horn            |
| 071 | Bassoon                 |
| 072 | Clarinet                |
| 073 | Piccolo                 |
| 074 | Flute                   |
| 075 | Recorder                |
| 076 | Pan Flute               |
| 077 | Blow Bottle             |
| 078 | Shakuhachi              |
| 079 | Whistle                 |
| 080 | Ocarina                 |
| 081 | Lead 1 (square)         |
| 082 | Lead 2 (sawtooth)       |
| 083 | Lead 3 (calliope)       |
| 084 | Lead 4 (chiff)          |
| 085 | Lead 5 (charang)        |
| 086 | Lead 6 (voice)          |
| 087 | Lead 7 (fifths)         |
| 088 | Lead 8 (bass + lead)    |
| 089 | Pad 1 (new age)         |
| 090 | Pad 2 (warm)            |
| 091 | Pad 3 (polysynth)       |
| 092 | Pad 4 (choir)           |
| 093 | Pad 5 (bowed)           |
| 094 | Pad 6 (metallic)        |
| 095 | Pad 7 (halo)            |
| 096 | Pad 8 (sweep)           |
| 097 | FX 1 (rain)             |
| 098 | FX 2 (soundtrack)       |
| 099 | FX 3 (crystal)          |
| 100 | FX 4 (atmosphere)       |

|     |                           |
|-----|---------------------------|
| 101 | FX 5 (brightness)         |
| 102 | FX 6 (goblins)            |
| 103 | FX 7 (echoes)             |
| 104 | FX 8 (sci-fi)             |
| 105 | Sitar                     |
| 106 | Banjo                     |
| 107 | Shamisen                  |
| 108 | Koto                      |
| 109 | Kalimba                   |
| 110 | Bagpipe                   |
| 111 | Fiddle                    |
| 112 | Shanai                    |
| 113 | Trinkle Bell              |
| 114 | Agogo                     |
| 115 | Steel Drums               |
| 116 | Woodblock                 |
| 117 | Taiko Drum                |
| 118 | Melodic Tom               |
| 119 | Synth Drum                |
| 120 | Reverse Cymbal            |
| 121 | Guitar Fret Noise         |
| 122 | Breath Noise              |
| 123 | Seashore                  |
| 124 | Bird Tweet                |
| 125 | Telephone Ring            |
| 126 | Helicopter                |
| 127 | Applause                  |
| 128 | Gunshot                   |
| 129 | Acoustic Grand Piano 1    |
| 130 | Bright Acoustic Piano 1   |
| 131 | Electric Grand Piano 1    |
| 132 | Honky-tonk Piano 1        |
| 133 | Electric Piano 1 1        |
| 134 | Electric Piano 2 1        |
| 135 | Harpsichord 1             |
| 136 | Clavinet 1                |
| 137 | Celesta 1                 |
| 138 | Glockenspiel 1            |
| 139 | Music Box 1               |
| 140 | Vibraphone 1              |
| 141 | Marimba 1                 |
| 142 | Xylophone 1               |
| 143 | Tubular Bells 1           |
| 144 | Dulcimer 1                |
| 145 | Drawbar Organ 1           |
| 146 | Percussive Organ 1        |
| 147 | Rock Organ 1              |
| 148 | Church Organ 1            |
| 149 | Reed Organ 1              |
| 150 | Accordion 1               |
| 151 | Harmonica 1               |
| 152 | Tango Accordion 1         |
| 153 | Acoustic Guitar (nylon) 1 |
| 154 | Acoustic Guitar (steel) 1 |
| 155 | Electric Guitar (Jazz) 1  |
| 156 | Electric Guitar (clean) 1 |
| 157 | Electric Guitar (muted) 1 |
| 158 | Overdriven Guitar 1       |
| 159 | Distortion Guitar 1       |
| 160 | Guitar Harmonics 1        |
| 161 | Acoustic Bass 1           |
| 162 | Electric Bass (finger) 1  |
| 163 | Electric Bass (pick) 1    |
| 164 | Fretless Bass 1           |
| 165 | Slap Bass 1 1             |
| 166 | Slap Bass 2 1             |
| 167 | Synth Bass 1 1            |
| 168 | Synth Bass 2 1            |
| 169 | Violin 1                  |
| 170 | Viola 1                   |
| 171 | Cello 1                   |
| 172 | Contrabass 1              |
| 173 | Tremolo Strings 1         |
| 174 | Pizzicato Strings 1       |
| 175 | Orchestral Harp 1         |
| 176 | Timpani 1                 |
| 177 | String Ensemble 1 1       |
| 178 | String Ensemble 2 1       |
| 179 | Synth Strings 1 1         |
| 180 | Synth Strings 2 1         |
| 181 | Choir Aahs 1              |
| 182 | Voice Oohs 1              |
| 183 | Synth Voice 1             |
| 184 | Orchestra Hit 1           |
| 185 | Trumpet 1                 |
| 186 | Trombone 1                |
| 187 | Tuba 1                    |
| 188 | Muted Trumpet 1           |
| 189 | French Horn 1             |
| 190 | Brass Section 1           |
| 191 | Synth Brass 1 1           |
| 192 | Synth Brass 2 1           |
| 193 | Soprano Sax 1             |
| 194 | Alto Sax 1                |
| 195 | Tenor Sax 1               |
| 196 | Baritone Sax 1            |
| 197 | Oboe 1                    |
| 198 | English Horn 1            |
| 199 | Bassoon 1                 |
| 200 | Clarinet 1                |

|     |                           |
|-----|---------------------------|
| 201 | Piccolo 1                 |
| 202 | Flute 1                   |
| 203 | Recorder 1                |
| 204 | Pan Flute 1               |
| 205 | Blow Bottle 1             |
| 206 | Shakuhachi 1              |
| 207 | Whistle 1                 |
| 208 | Ocarina 1                 |
| 209 | Lead 1 (square) 1         |
| 210 | Lead 2 (sawtooth) 1       |
| 211 | Lead 3 (calliope) 1       |
| 212 | Lead 4 (chiff) 1          |
| 213 | Lead 5 (charang) 1        |
| 214 | Lead 6 (voice) 1          |
| 215 | Lead 7 (fifths) 1         |
| 216 | Lead 8 (bass + lead) 1    |
| 217 | Pad 1 (new age) 1         |
| 218 | Pad 2 (warm) 1            |
| 219 | Pad 3 (polysynth) 1       |
| 220 | Pad 4 (choir) 1           |
| 221 | Pad 5 (bowed) 1           |
| 222 | Pad 6 (metallic) 1        |
| 223 | Pad 7 (halo) 1            |
| 224 | Pad 8 (sweep) 1           |
| 225 | FX 1 (rain) 1             |
| 226 | FX 2 (soundtrack) 1       |
| 227 | FX 3 (crystal) 1          |
| 228 | FX 4 (atmosphere) 1       |
| 229 | FX 5 (brightness) 1       |
| 230 | FX 6 (goblins) 1          |
| 231 | FX 7 (echoes) 1           |
| 232 | FX 8 (sci-fi) 1           |
| 233 | Sitar 1                   |
| 234 | Electric Piano 2 1        |
| 235 | Shamisen 1                |
| 236 | Koto 1                    |
| 237 | Kalimba 1                 |
| 238 | Bagpipe 1                 |
| 239 | Fiddle 1                  |
| 240 | Shanai 1                  |
| 241 | Trinkle Bell 1            |
| 242 | Agogo 1                   |
| 243 | Steel Drums 1             |
| 244 | Woodblock 1               |
| 245 | Taiko Drum 1              |
| 246 | Melodic Tom 1             |
| 247 | Synth Drum 1              |
| 248 | Reverse Cymbal 1          |
| 249 | Guitar Fret Noise 1       |
| 250 | Breath Noise 1            |
| 251 | Seashore 1                |
| 252 | Bird Tweet 1              |
| 253 | Telephone Ring 1          |
| 254 | Helicopter 1              |
| 255 | Applause 1                |
| 256 | Gunshot 1                 |
| 257 | Acoustic Grand Piano 2    |
| 258 | Bright Acoustic Piano 2   |
| 259 | Electric Grand Piano 2    |
| 260 | Honky-tonk Piano 2        |
| 261 | Electric Piano 1 2        |
| 262 | Electric Piano 2 2        |
| 263 | Harpsichord 2             |
| 264 | Clavinet 2                |
| 265 | Celesta 2                 |
| 266 | Glockenspiel 2            |
| 267 | Music Box 2               |
| 268 | Vibraphone 2              |
| 269 | Marimba 2                 |
| 270 | Xylophone 2               |
| 271 | Tubular Bells 2           |
| 272 | Dulcimer 2                |
| 273 | Drawbar Organ 2           |
| 274 | Percussive Organ 2        |
| 275 | Rock Organ 2              |
| 276 | Church Organ 2            |
| 277 | Reed Organ 2              |
| 278 | Accordion 2               |
| 279 | Harmonica 2               |
| 280 | Tango Accordion 2         |
| 281 | Acoustic Guitar (nylon) 2 |
| 282 | Acoustic Guitar (steel) 2 |
| 283 | Synth Voice 2             |
| 284 | Electric Guitar (clean) 2 |
| 285 | Electric Guitar (muted) 2 |
| 286 | Trombone 2                |
| 287 | Distortion Guitar 2       |
| 288 | Guitar Harmonics 2        |
| 289 | Acoustic Bass 2           |
| 290 | Electric Guitar (Jazz) 2  |
| 291 | Electric Bass (finger) 2  |
| 292 | Fretless Bass 2           |
| 293 | Slap Bass 1 2             |
| 294 | Slap Bass 2 2             |
| 295 | Synth Bass 1 2            |
| 296 | Synth Bass 2 2            |
| 297 | Violin 2                  |
| 298 | Viola 2                   |
| 299 | Cello 2                   |
| 300 | Contrabass 2              |

|     |                         |
|-----|-------------------------|
| 301 | Tremolo Strings 2       |
| 302 | Pizzicato Strings 2     |
| 303 | Orchestral Harp 2       |
| 304 | Timpani 2               |
| 305 | String Ensemble 1 2     |
| 306 | String Ensemble 2 2     |
| 307 | Synth Strings 1 2       |
| 308 | Synth Strings 2 2       |
| 309 | Choir Aahs 2            |
| 310 | Voice Oohs 2            |
| 311 | Synth Voice 2           |
| 312 | Orchestra Hit 2         |
| 313 | Trumpet 2               |
| 314 | Trombone 2              |
| 315 | Tuba 2                  |
| 316 | Muted Trumpet 2         |
| 317 | French Horn 2           |
| 318 | Brass Section 2         |
| 319 | Synth Brass 1 2         |
| 320 | Synth Brass 2 2         |
| 321 | Soprano Sax 2           |
| 322 | Alto Sax 2              |
| 323 | Tenor Sax 2             |
| 324 | Baritone Sax 2          |
| 325 | Oboe 2                  |
| 326 | English Horn 2          |
| 327 | Bassoon 2               |
| 328 | Clarinet 2              |
| 329 | Piccolo 2               |
| 330 | Flute 2                 |
| 331 | Recorder 2              |
| 332 | Pan Flute 2             |
| 333 | Blow Bottle 2           |
| 334 | Shakuhachi 2            |
| 335 | Whistle 2               |
| 336 | Ocarina 2               |
| 337 | Lead 1 (square) 2       |
| 338 | Lead 2 (sawtooth) 2     |
| 339 | Lead 3 (calliope) 2     |
| 340 | Lead 4 (chiff) 2        |
| 341 | Lead 5 (charang) 2      |
| 342 | Lead 6 (voice) 2        |
| 343 | Lead 7 (fifths) 2       |
| 344 | Lead 8 (bass + lead) 2  |
| 345 | Pad 1 (new age) 2       |
| 346 | Pad 2 (warm) 2          |
| 347 | Pad 3 (polysynth) 2     |
| 348 | Pad 4 (choir) 2         |
| 349 | Pad 5 (bowed) 2         |
| 350 | Pad 6 (metallic) 2      |
| 351 | Pad 7 (halo) 2          |
| 352 | Pad 8 (sweep) 2         |
| 353 | FX 1 (rain) 2           |
| 354 | FX 2 (soundtrack) 2     |
| 355 | FX 3 (crystal) 2        |
| 356 | FX 4 (atmosphere) 2     |
| 357 | FX 5 (brightness) 2     |
| 358 | FX 6 (goblins) 2        |
| 359 | FX 7 (echoes) 2         |
| 360 | FX 8 (sci-fi) 2         |
| 361 | Sitar 2                 |
| 362 | Banjo 2                 |
| 363 | Shamisen 2              |
| 364 | Koto 2                  |
| 365 | Kalimba 2               |
| 366 | Bagpipe 2               |
| 367 | Fiddle 2                |
| 368 | Shanai 2                |
| 369 | Trinkle Bell 2          |
| 370 | Agogo 2                 |
| 371 | Steel Drums 2           |
| 372 | Woodblock 2             |
| 373 | Taiko Drum 2            |
| 374 | Melodic Tom 2           |
| 375 | Synth Drum 2            |
| 376 | Reverse Cymbal 2        |
| 377 | Guitar Fret Noise 2     |
| 378 | Breath Noise 2          |
| 379 | Seashore 2              |
| 380 | Bird Tweet 2            |
| 381 | Telephone Ring 2        |
| 382 | Helicopter 2            |
| 383 | Applause 2              |
| 384 | Gunshot 2               |
| 385 | Acoustic Grand Piano 3  |
| 386 | Bright Acoustic Piano 3 |
| 387 | Electric Grand Piano 3  |
| 388 | Honky-tonk Piano 3      |
| 389 | Electric Piano 1 3      |
| 390 | Electric Piano 2 3      |
| 391 | Harpsichord 3           |
| 392 | Clavinet 3              |
| 393 | Celesta 3               |
| 394 | Glockenspiel 3          |
| 395 | Music Box 3             |
| 396 | Vibraphone 3            |
| 397 | Marimba 3               |
| 398 | Xylophone 3             |
| 399 | Tubular Bells 3         |
| 400 | Dulcimer 3              |

## Socket Location



1.Operating Voltage:Input Voltage Range DC 5V.

2.Indicator Light: Press Power On,is lighting.

3.The headphone Jack : Connect the headphone will cut off the output of the speaker automatically, it won't affect others when playing .

4.Audio Input or Output : Input to play songs , Output to connect the Sound Equipment.

5.Sustain Pedal: this product has sustain sound pedal function, Please step on the pedal according to the playing requirement

6.MIDI port : use data cable to connect computer, mobile phone or ipad to open corresponding software can use MiDI function,transmit and receive MiDI signal.

7.Three-pedal pedal: can be connected with the three-pedal function (grand piano) to meet the needs of the customers on different occasions to

play


# Manual for electric piano

# Demo List

**Special reminder:** This product is an electronic product. After electrified, the loudspeaker (two horns or one horn, earphone) has some current sound as a normal phenomenon. It is necessary to keep away from these devices, such as radio, routers, TV receivers, refrigerators, washing machines, etc.

## Power Supply

This product can be supplied by standard indoor wall socket, please use only the power cord specified by this product. When you do not use, please be sure to turn off the power supply, if you do not use it for a long time, please pull out the power cord and keep it properly.



## Sign

In order to ensure that you are safe and correct use of this product, to prevent damage to the user and other people, and to the financial damage, the specification and the product marked with a series of safety signs. All kinds of signs and their meaning.

### Warning

This sign indicates that, if you ignore the flag and error operation of this product, there is a potential risk of death or serious injury to personnel.

### Attention

This sign indicates that, if you ignore the flag and the wrong operation of this product, there is a potential risk of injury or other financial damage caused by personnel.

## Logo example



This triangle mark indicates that the user should pay attention to the matters. (left case is be careful electric shock)



The circular sign painting a slash said prohibited matters. The icon in the logo or next to the specific content of the banner. (left case is no disassemble)



Black dots indicate matters must be complied with. Icon in this sign indicates the specific content that must be followed. (left case is the power plug must be pulled out of the socket)

## Warning

### Smoke, odor, overheating

When the product is smoking, emitting odors or overheating, it continues to be used to cause fire and electric shock. In the event of such a situation, the following operations shall be carried out immediately.

- 1 Turn off the power supply.
- 2 Pull the plug from the power outlet.
- 3 Contact your agency

### Power cord

● Improper use of power supply leads to danger of fire and electric shock. Must observe the following precautions.

- Special power lines specified for this product must be used.

● An AC power source with output voltage within the household rated voltage must be used.

- It is not allowed to overload the power socket and the power extension line.
- Improper handling of power lines, resulting in damage or rupture of the fire and the risk of electric shock. Must observe the following precautions.

- Do not place heavy objects on the power line or make them heated.
- Do not attempt to transform the power cord or bend it too much.
- Do not twist or pull the power cord.
- If the power cord or plug is damaged, replace the power cord of the same type.
- Do not use wet hands to touch the power cord and plug, otherwise there is a risk of electric shock.

● Please use the power cord in the place where the water will not be spilled. Water has the risk of fire and electric shock.

- Never put a vase or any other container with water in this product. Water has the risk of fire and electric shock.

- Do not let the minor contact plug and power line or a connecting plate. Minor knowledge of useless electricity safety causes danger of electric shock.

● Improper use of power supply leads to danger of fire and electric shock. The following matters of attention must be observed.

- Do not place the power cord near the furnace or other heat sources.
- Unplug the power cord from the power outlet. Must grasp the plug body.
- Plug the power cord into the power socket.
- Before connecting or cutting off the power cord, make sure that the power is off.
- The power cord should be removed from the electrical outlet of the wall before a thunderstorm occurs or traveling or before other long leave.
- At least once a year, unplug the power cord from the wall outlet and clean the dust around the plug.



● Improper use of power supply leads to danger of fire and electric shock. Must observe the following precautions.

● At least once a year, unplug the power cord from the wall outlet and clean the dust around the plug.

### Don't burn this product

Do not put this product into the fire, otherwise it will cause the burning of wood products and the explosion of the internal electronic components. There is a danger of fire and personnel injury

### Water and foreign matter

Water and other liquids and (metal) into this product has the risk of causing fire and electric shock. The following operation should be performed immediately when the above situation occurs.

- 1 turn off the power supply
- 2 if the power cord is used for power supply, it will be pulled off from the wall of the power outlet
- 3 contact your dealer.

### Dismantling and rebuilding

Do not disassemble this product or transform it in any way. Otherwise it will be hazardous to electrical shock, burns or other personal injury. All internal inspection, adjustment and maintenance operations should be entrusted to your dealer.

|        |                               |        |                                           |
|--------|-------------------------------|--------|-------------------------------------------|
| Song01 | Dreams                        | Song45 | London Bridge                             |
| Song02 | The imprint of rain           | Song46 | Look At All The Colors I Can See          |
| Song03 | Arabic Style Song No.1        | Song47 | Menuetto                                  |
| Song04 | Tragic Sonata, Third Movement | Song48 | Bingo                                     |
| Song05 | For Alice                     | Song49 | Spanish Bullfighter March                 |
| Song06 | let's row our boats           | Song50 | Prelude (Wohltemperierte Klavier 1-1)     |
| Song07 | flower fairy                  | Song51 | six little ducks                          |
| Song08 | William Tell Overture         | Song52 | romance de amor                           |
| Song09 | The Blue Danube               | Song53 | dance of fireflies                        |
| Song10 | The sound of snow falling     | Song54 | Riding on the wings of that singing voice |
| Song11 | childhood                     | Song55 | The Maiden's Prayer                       |
| Song12 | Love And Passion              | Song56 | The Entertainer                           |
| Song13 | Little Star                   | Song57 | Premiere arabesque                        |
| Song14 | Cannon                        | Song58 | Aura Lee                                  |
| Song15 | Skip to my lou                | Song59 | Honky-Tonk                                |
| Song16 | US Patrol Troops              | Song60 | La Violette                               |
| Song17 | Turkey In the Straw           | Song61 | Claire De Lune                            |
| Song18 | Yankee doodle                 | Song62 | Chopin Nocturne Op.9                      |
| Song19 | Many years ago                | Song63 | Melody F                                  |
| Song20 | Mary Had A Little Lamb        | Song64 | Rondo K.V.485                             |
| Song21 | Old Black Joe                 | Song65 | Tango Espana                              |
| Song22 | Romeo and Juliet              | Song66 | Liebest?ume Nr. 3                         |
| Song23 | Two tigers                    | Song67 | Londonderry Air                           |
| Song24 | My Bonnie                     | Song68 | Green sleeves                             |
| Song25 | Row, Row, Row Your Boat       | Song69 | Souvenir De Moscou op.6                   |
| Song26 | Christmas song                | Song70 | Leggenda Valacca                          |
| Song27 | Happy Clapping Song           | Song71 | Wild bees fluttering and dancing          |
| Song28 | jingle bells                  | Song72 | March in D                                |
| Song29 | Croatian Rhapsody             | Song73 | To a Wild Rose                            |
| Song30 | Above the Moon                | Song74 | Cherni 599-001                            |
| Song31 | The Song of Leo               | Song75 | Chelny 599-002                            |
| Song32 | Sha Bao                       | Song76 | Cherni 599-003                            |
| Song33 | It's a small world            | Song77 | Cherni 599-004                            |
| Song34 | Moonlight over the lotus pond | Song78 | Chelny 599-005                            |
| Song35 | Hongyan                       | Song79 | Cherni 599-006                            |
| Song36 | Mozart's Symphony No. 40      | Song80 | Cherni 599-007                            |
| Song37 | Rock A Bye Baby               | Song81 | Chelny 599-008                            |
| Song38 | Red River Valley              | Song82 | Cherni 599-009                            |
| Song39 | Clarinet Polka                | Song83 | Chelny 599-010                            |
| Song40 | Mr. Wang has a piece of land  | Song84 | Chelny 599-011                            |
| Song41 | The wheels on the bus         | Song85 | Chelny 599-012                            |
| Song42 | Carmen                        | Song86 | Chelny 599-013                            |
| Song43 | Apple Round, Apple Red        | Song87 | Cherni 599-014                            |
| Song44 | Little bee                    | Song88 | Chelny 599-015                            |

## **FCC Warning**

### **15.19 Labeling requirements.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **15.21 Information to user.**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **15.105 Information to the user.**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.